

A8000


User's Manual
Mode d'emploi
Benutzerhandbuch
Instrucciones de empleo
Gebruikershandleiding
Руководство пользователя
取扱説明書
使用说明书



Manufacturer / Fabricant / Hersteller /
Fabricante / Fabrikant / Производитель / 製造

S'NEXT Co., Ltd.
3-12-7 Kitakase, Saiwai-ku,
Kawasaki-shi, Kanagawa
212-0057, Japan
Tel: +81 44 789 5795
Fax: +81 44 789 5770

Part Names



List of items in package

Main unit, Carrying case, Ear tips, Ear tips case, Ear hooks TYPE B, MMCX ASSIST, Dust filters

Regarding Ear Hooks

Using the ear hooks makes for an even more stable fit, and also makes for a reduction in touch noise.

-How to put them on

Please put the ear hooks onto the cable. Next, while holding down the base of the lock on the ear hooks, pull the hole over the lock from above and push it down to lock it in place. Then, insert the housings of the earphone into the ear and hang the ear hooks on the ear and adjust the fit.

※ The ear hook was not designed to be removed. Be forewarned that repeated removal makes it easy to damage the hole on the locking mechanism. If frequent removal is required, please use the Type A ear hooks sold separately.



Please scan the QR code or access the link below to view a how to video.

<https://youtu.be/svQVyxShM0>




Regarding MMCX ASSIST

Use of MMCX ASSIST makes it surprisingly easy to remove the MMCX plug by the application of appropriate force in the direction of cable removal while preventing cable breakage.

-How to use

Align the pincers of MMCX ASSIST with the juncture of the MMCX interface and gently apply pressure. (※Below diagram depicts the E5000 chassis.)



Please scan the QR code or access the link below to view a how to video.

<https://youtu.be/g7XypNlq090>



Note on use of the detachable cable

• The connecting terminal has not been configured with a view to frequent connection and disconnection. Repeatedly connecting and disconnecting the terminal may lead to contact failure owing to wear or damage to the terminal; please ensure that any connection or disconnection is limited to situations of cable breakage or when the cable is replaced with other final cables that are sold separately.

• To prevent damage to the connecting terminal, please ensure that all parts are held straight when connecting or disconnecting them.


• Never tug on the cable in order to remove it; always use the MMCX ASSIST included with this product. Refer to the how-to-use information above.

• In the event that evidence of excess wear or damage to the connecting terminal is recognized, the product will not be covered by the warranty, even during the warranty period.

Regarding earpieces

To make it easier to differentiate between the right and left earpieces, we have given the bushes different colors; the bush of one earpiece is gray, while the other is red. (*1) By pulling the earpiece back slightly to check the color of the bush, it is easy to distinguish between left and right, even in places with subdued lighting.

Since the bush colors of neighboring sizes are different (the gray bushes alternate between dark and light gray; the red bushes alternate between red and pink), it is also easy to distinguish between sizes. (*2)



Regarding the carry case

Turn the lid back to open the case; store the earphones inside, then close the lid, ensuring that all three tabs are securely fastened. The lid may open if the case is exposed to inordinate force.

Please scan the QR code or access the link below to view a how to video.

<https://youtu.be/Tb0mNsces6s>



Notes on use



A8000 is made of metal. Please be aware that metal parts may come into direct contact with your skin. Therefore, if you have an allergy to metal you should not use this product. Also, if you experience skin irritation, stop using the product immediately and seek medical attention. When using the product in cold climates, be sure not to allow the product to strongly contact with your skin.



Ignoring the content of this indication could result in death or serious injury.



Do not use the earphones while driving a bicycle, car or motorcycle. Doing so could cause a traffic accident and/or serious injury.



Do not use the product while walking in dangerous environments such as near a railroad crossing or intersection where you cannot hear sounds from the outside.



Ignoring the content of this indication could cause injury or damage to household articles in the vicinity.



When using the earphones, be careful not to play the sound too loud. Doing so for a long period of time could affect your hearing. At 80 dB(A) exposure time shall be limited to 40 hours/week, whereas at 89 dB(A) exposure time shall be limited to 5 hours/week.



If you experience skin irritation, stop using the product immediately and seek medical attention, or consult with our sales agent.



If the sound volume is too loud, sound can be heard by other people. Use care not to disturb other people.

• The way you position the earphone in your ear affects the sound quality. We recommend trying different positions by moving the earphone around while playing music. This will allow you to find the position that generates your most preferred sound. Once you figure out your favorite position it will be easy to set that position each time. The shapes of a person's right ear and left ear are usually different. Therefore, the best position for each ear is usually different as well.

• When removing the earphone from your ears, always hold the main unit first and then remove. Pulling the cord could cause the wire to become disconnected.

• Because the housing is made of metal, if you bring the earphone from a cold environment and the temperature rapidly changes, condensation could occur inside the housing. In such a case, leave it for a while until any condensation inside the unit evaporates and then use the product.

• Do not apply strong impacts to the earphones or put excess force on the cable. If the product fails or wires are broken due to abnormal use, the product warranty is invalidated.

• Leaving the product in locations exposed to direct sunlight, high humidity, or a dusty environment could cause the product to fail.

• If the product fails, do not attempt to disassemble.

• The earphone jack is for stereo reproduction only. If the earphone is connected to a monaural output jack, sound may not come out of one side.


Maintenance

Gently remove debris stuck in the dust filter by tweaking it out onto the tip of a toothpick. In case soil or debris cannot be removed, please replace the dust filter with a new one included as accessory. Please refer to the text below regarding the methodology for replacement of the dust filter.

The cable may harden if it comes into contact with certain chemical agents and in particular with the natural oils in human skin. After using the product, please wipe the cable with a soft damp cloth. Please refrain from using wet wipes that contain alcohol; using these may result in hardening of the product. Please also refrain from using alcohol-free wet wipes; these may contain a variety of other additives which may adversely affect the product.

How to replace the Dust Filters

1. Use tweezers or similar to remove the old dust filter from the sound canal.
2. Remove a new dust filter from the dust filter sheet included in the product package.
3. Place the dust filter in the sound canal and gently press with tweezers or similar to affix the adhesive portion.



Warranty and after-sales service

The warranty for this product is valid for 2 years from the day of purchase. During the warranty period, we will repair the product based on the provisions below. The warranty is only valid in the country in which the product was purchased. Please contact the store you purchased the product from regarding questions pertaining to repairs. For products purchased outside your country of residence and for support after the warranty period, please contact us using the Contact Form on our website.

1. During the warranty period, we will repair the product free of charge if the product failed even though it was used in accordance with the instructions in the User's Manual and the Warning and Caution sections.
2. In the following cases, repairs to the product will be subject to a fee even during the warranty period:
 - (1) The necessary documentation noted in the warranty card is not complete.
 - (2) The earphones were subjected to a strong impact or were allowed to get wet. Product failure or broken wires resulting from an excessive use of force on the cables.
 - (3) Failure of the product or damage caused as a result of fire, earthquake, storm or flood damage, lightning strike or other natural disaster.
 - (4) Repair of scratches on the surface of the housing or repair of the housing itself.


Contacting us

Please contact us regarding inquiries using the Contact Form on our website: www.snext-final.com

Specifications

Product code	FI-A8DSSD	Impedance	16 Ω
Housing	Stainless steel	Sensitivity	102 dB/mW
Driver	Dynamic	Weight / Cable length	41 g / 1.2 m

各部の名称



同梱品

本体、キャリーケース、イヤピース、イヤピースケース、イヤフック TYPE B、MMCX ASSIST、交換用ダストフィルター


イヤフックについて

イヤフックを使うと筐体をさらに安定して装着でき、またタッチノイズを軽減することができます。

・装着方法

イヤフックをケーブルに装着してください。次にロック機構部のロックの根元を押さえながら、ホールを上からロックに被せるように押し込んで固定してください。その後、筐体を耳に挿入し、イヤフックを耳にかけて、フィット感を調整してください。

※イヤフックはシリコンの柔らかさと、ケーブルにしっかりと固定される最適な形状を両立するため、イヤフックを取り付け後に、取り外しを想定した設計ではありません。頻繁に取り外しをする場合は別売の「Ear hooks TYPE A」をご利用ください。



装着方法動画は下記リンクもしくはQRコードよりご覧ください。

<https://youtu.be/svQVyxShM0>




MMCX ASSIST について

MMCX ASSIST を使用すると、MMCX コネクタに対してケーブルが抜ける方向に正しく力が加わり、驚くほど簡単に取り外すことができ、ケーブル断線を防ぐことができます。

・使用方法

MMCX ASSIST のツメ部分を MMCX 端子の接合部分に合わせ、ゆっくりと力を入れてください。(※下図の筐体は E5000 です)



使用方法動画は下記リンクもしくはQRコードよりご覧ください。

<https://youtu.be/g7XypNlq090>



着脱式ケーブルの注意点

・接続端子は頻繁な抜き差しを想定したものではありません。着脱を繰り返すと、端子の摩耗や破損による接触不良を引き起こす事がございますので、ケーブル断線時の交換や弊社別売ケーブルへの交換以外での着脱はお控えください。


・接続端子の破損を防ぐ為、まっすぐ抜き差しを行なってください。

・取り外しの際はケーブルを引っ張らず、必ず同梱の MMCX ASSIST をご使用ください。使用方法は上記をご参照ください。

・接続端子に過度の摩耗や破損の形跡が認められた場合は保証期間内でも保証対象外となります。

イヤピースについて

左右判別をしやすい為、軸色を、片方はグレー、もう一方は赤にしています。(*1) イヤピースを少しめくって軸色を確認することで、薄暗い場所でも左右の判別がしやすくなっています。さらに、隣のサイズの軸色を変えておりますので(グレー軸は濃いグレーと薄いグレーの交互、赤軸は赤とピンクの交互)、サイズの判別もしやすくなっています。(*2)



キャリーケースについて

裏返して蓋を開けてイヤホンを収納し、蓋を閉じて3箇所あるツメがしっかりと留まっていることを確認してください。過度の衝撃が加わると、蓋が開いてしまう場合がございます。十分にご注意ください。

収納方法は下記リンクもしくはQRコードより動画をご参照ください。

<https://youtu.be/xzhwqs1agTQ>



使用上の注意



注意

A8000は金属製です。直接金属面が肌に触れる設計となっておりますので、金属アレルギーをお持ちの方はご使用にならないでください。また、皮膚にあわないと感じられた際には、すみやかに使用を中止し、医師にご相談ください。また、寒冷地でのご使用の際には、肌に無理のないようご注意ください。



警告

この表示を無視して誤った取り扱いをすると、人が死亡または重傷を負う原因となる内容を示しています。



禁止

自転車や自動車、オートバイなどを運転しながらのイヤホンの使用は絶対に避けてください。交通事故を引き起こす原因となり、重大な結果を引き起こす恐れがあります。



禁止

運転以外であっても、踏切や交差点他、周囲の音が聞こえないと危険な環境では、ご使用にならないでください。



注意

この表示を無視して誤った取り扱いをすると、人が負傷を負う、または周辺の家財に損害を与える可能性がある内容を示しています。



禁止

イヤホンをご使用の際には、音量を上げすぎないように気をつけてください。長時間、大音量での使用は、難聴を引き起こす可能性があります。80 dB(A)の音量で40時間/週、89 dB(A)の音量で5時間/週を超えないようにしてください。



禁止

イヤホンが肌にあわないと感じられた際には、お早めに使用を中止し、医師もしくは販売店に相談ください。



禁止

音量を上げすぎると、音は外部に漏れます。周囲の人の迷惑にならないように気をつけてください。

・装着位置によって音質が大きく変化致します。音楽を再生しながら片方ずつ本体を立体的に動かし、最も好ましく聞こえる位置に合わせてください。それがベストポジション(最適位置)です。一度体験すると、二度目からは無理なく位置を合わせる事が可能です。通常耳の形状は左右で大きく異なります。そのため、ベストポジションは左右の耳で異なります。

・耳からイヤホンを外す際には、本体を持って外してください。ケーブルを持ち引っ張って外すと、ケーブル断線の原因となります。

・筐体が金属製のため、寒い戸外から室内へ持ち込むなど、急激な温度変化の際、筐体内部で結露します。その際はしばらく時間を置いて、内部が乾燥してからご使用ください。

・イヤホンに強い衝撃を与えたり、ケーブルに無理な力が加からないようにしてください。異常な使用状況下での故障や断線等は保証の対象外となります。

・直射日光の当たる場所、湿気、埃他の多い環境に放置すると、故障の原因となります。

・故障の際は内部を開けたりしないでください。

・このイヤホンのプラグはステレオ再生専用となっています。モノラル出力ジャックに接続した場合には、片側から音が出ない可能性があります。

メンテナンス


ダストフィルターに付着したゴミは、爪楊枝の先端にゴミを付着させる形でやさしく取り除いてください。内部にゴミが落下しないように、気をつけて作業してください。汚れが取れない場合は、新しいダストフィルターと交換してください。ダストフィルター交換方法については下記をご参照ください。



ケーブルは様々な化学物質、特に皮脂と反応し、硬化する場合がございます。製品使用後は、ケーブルを水で少し湿らせた柔らかい布で拭いて下さい。硬化の原因となりますので、アルコール入りのウエットティッシュのご使用をお控えください。ノンアルコールのウエットティッシュも様々な添加剤が入っている可能性がありますのでご使用をお控えください。

ダストフィルター交換方法

1. ピンセットなどを使い、古いダストフィルターを取り除く。
2. シートからダストフィルターをはがす。
3. 筐体と同心円状にダストフィルターを置き、ピンセット等で粘着部分を押しあてつけて接着する。



保証とアフターサービス

この製品の保証期間はご購入日より2年間です。保証期間中は以下の保証規定に基づき修理致します。保証はご購入頂いた国でのみ有効です。修理のお申込は弊社ウェブサイトの「CONTACT」ページの「修理申込フォーム」より行なってください。居住国以外の国でご購入の場合や保証期間後のサポートについては、弊社ウェブサイトの「CONTACT」ページの「お問い合わせフォーム」よりお問い合わせください。

1. 保証期間内に、取扱説明書に記載の警告、注意書きに従った使用状態で故障した場合には、無償修理させていただきます。
2. 保証期間内で次の場合には、有償で修理させていただきます。
 - (1) 保証書に記載の必要書類が揃っていない場合。
 - (2) イヤホンに強い衝撃を与えたり、水に濡らした場合。ケーブルに無理な力が加かるような状況下で起こった故障や断線。
 - (3) 火災、地震、風水害、落雷、その他天変地異などによる故障及び損傷。
 - (4) 筐体表面の傷の修理、筐体自体の修理。

お問い合わせ

弊社ウェブサイトの「CONTACT」ページの「お問い合わせフォーム」よりお問い合わせください。
www.snext-final.com

仕様

製品コード	FI-A8DSSD	インビードダンス	16 Ω
筐体	ステンレス	感度	102 dB/mW
ドライバー	ダイナミック型	重量/ケーブル長	41 g / 1.2 m